

PHA 5% MILD EXFO ESSENCE



Trendy Formulation

4604FOR1 (April 2022)



PHASE	INCI / PCPC	TRADE NAME	SUPPLIER	w/w %
A.1	Water (aqua)	-	-	70,00
A.2	1,3-Propanediol	-	-	3,00
A.3	Hydroxyethylcellulose	Natrosol™ 250HR	Ashland	0,70
A.4	Lactobacillus Ferment	Leucidal® SF Max	Active Micro Technologies	4,00
A.5	Aqua, Glycerin, Gluconolactone, Mel, Lactobionic Acid	APIBREEZE™	Provital	20,00
A.6	Water (Aqua), Sodium Hydroxide	-	-	2,30
			TOTAL	100,00

PROCEDURE

1. In a clean beaker, heat A.1 +A.2 to 75°C and add A.3 under stirring until it is fully dispersed.
2. Then cool down under stirring to 30°C for adding the rest of the ingredients one by one waiting for homogeneity between each addition.

CONTROL

Appearance: yellow clear gel.
pH: 3.5-4.2
Viscosity (20°C, 100 rpm, spindle 6): 50-600 mPa.s
Stability Test: 2 months at 50°C, 40°C and RT.

DIRECTIONS

Twice a week, apply this concentrated serum on dry, clean and unbroken skin, avoiding eye contour, then continue with your skin care routine, As PHA's are milder than AHA's there is no need for extra UV protection.

TARGET

All skin types.

**NATURAL ORIGIN
CONTENT (ISO 16128)**
99.3%

EWG
1 - 2

COMPLIANCE



This information is based on Provital present knowledge and experience. However, Provital does not warrant its fitness for a particular purpose, merchantability, performance, safety, microbiological profile or freedom from patent infringement. It is not a commercial formulation and has not been subjected to extensive testing. It is the customer's responsibility and obligation to carefully test any formulations before use. Provital shall not be responsible for consequential, indirect or incidental damages (including loss of profits) of any kind. All warranties, indemnities or liabilities implied or expressed by law are hereby excluded by Provital to the full extent permitted by law.