

WARM-UP MIST

Warm-up your muscle, then grab the mist and energize your skin with the explosives fruit extracts and the biotech cellular energizer. Prepare yourself for the most important race of your life!

CLAIMS & KEY POINTS

- *Water-free*
- *Skin energizer*
- *Skin protection*
- *Refreshing effect*

CytoFruit® Water Sweet Orange BIO⁹⁹, a re-energizing wave

CytoFruit® Water Kiwi BIO⁹⁹, a reinvigoration protection

Ener-GY plus, cell energizer from Mediterranean sources

Formula protection made by **BiosControl® Evolve PTG** and **Element SB**

SKIN CARE

MAKE SUSTAINABILITY REAL



WARM-UP MIST

C.SK.23.53HPC

| Trade Name | INCI | % |
|---|---|---------------|
| A | | |
| CytoFruit® Water Sweet Orange BIO⁹⁹ | Citrus Aurantium Dulcis Fruit Extract, Potassium Sorbate | 47,30 |
| CytoFruit® Water Kiwi BIO⁹⁹ | Actinidia Chinensis Fruit Extract, Potassium Sorbate | 45,00 |
| Olifeel® Glycerin | Glycerin | 3,00 |
| Ener-GY plus | Citrus Limon Fruit Extract, Glyceryl Glucoside, Glycerin, Potassium Sorbate | 1,00 |
| BiosControl® Evolve PTG | Pentylene Glycol | 3,00 |
| BiosControl® Element SB | Sodium Benzoate | 0,30 |
| B | | |
| | Parfum | 0,40 |
| TOTAL | | 100,00 |

CHEMICAL PHYSICAL PARAMETERS:

1. Appearance: LIQUID TRANSPARENT
2. Colour: YELLOWISH
3. Smell: CHARACTERISTIC
4. pH: 5-5,5
5. Density (g/ml): 1,0 g/ml
6. Viscosity: n.a.
7. Centrifuge (2 cycle*3000rpm*15'): n.a.
8. Stability (6 months at 4, 25, 40°C): YES
9. Dropping point (°C): n.a.
10. Surfactant actives content: n.a.

MANUFACTURING METHOD:

1. Weight one by one the components of Phase A and mix slowly until complete dissolution;
2. Weight Phase B, heat if it is necessary;
3. Add Phase B into Phase A;
3. Control all the parameters required and, if necessary, adjust the pH.

